

◀◀◀ **WARNING: READ THIS BEFORE USING PRODUCT!** ▶▶▶

QUICK START GUIDE

[ACT-IR2002UL/ACT-IR4002US GENERAL SETUP PROCEDURE]

1. Insert the installation CD.
2. If you are running **Windows 98/ME/2000/XP/Vista & 7(32 or 64 bit)**, make sure IR dongle is **NOT** plugged into USB beforehand.
3. Make sure you have enabled Autorun if your PC is running **Windows Vista & 7(32 or 64 bit)**.
4. The Autorun wizard will automatically initialize the driver installation. The driver installation will exit without any prompts to the user after successful installation.
5. Now plug in the ACT-IR2002UL / ACT-IR4002US adapter into USB port. There will be a pop showing, you plugged in an IR dongle as shown in the manual
6. For **WinCE, Mac or Linux OS**, you have to manually install the driver.
7. Please refer to the chapter of "installation" in the manual.

Note:

1. It should be noted that some versions of Windows 7/Vista have native drivers so you can directly plug and play without installing the driver.